



Transverse beam: Milled on a MIKRON HPM 600


For applications with high material removal requirements in a short time with an accuracy of 20 µm and a surface scallop height of 2 µm, efficient CAM strategies are needed that can provide a high chip-to-time ratio. hyperMILL® offers powerful 2D, 3D and 5axis strategies for fast machining. Thanks to the software's feature technology, recurring job sequences such as pocket roughing can easily be automated.



Stock roughing: The blank is machined level by level with a large tool in contour-parallel mode. The shortest possible tool stick-out can be calculated using collision detection and avoidance. As a result, higher



Rest material roughing: In combinati- **Tapping:** Drill feature recognition on with stock tracking, the "Arbitrary stock roughing" cycle can also be used for rest machining. Thanks to precise machining status feedback for the blank, milling only proceeds in process parameters can be achieved. areas where rest material is detected.



searches all the models within a defined area for drillings and also detects tappings. This speeds up programming for all types of drillings.



Machine: MIKRON HPM 600

	Job description	Tool	Diameter [mm]	Corner radius [mm]	No. of teeth	Spindle RPM [min [:]]	Feedrate [mm/min]	step-over width [mm]	Infeed depth [mm]	Machining time [min']	
			D	R	z	n	$\mathbf{v}_{_{\mathrm{f}}}$	a _e	a _p	t	
	Roughing	Endmill	16	o	2	16.000	3.800	8-16	4	17'00"	
	Rest material roughing	Endmill	10	0	2	20.000	4.500	5	5	7'42"	
	Finishing	Endmill	10	o	2	20.000	4.500	0,2	11	4'11"	
	Rest material roughing	Endmill	5	0	2	20.000	2.000	2,5	2	7'00"	
	Finishing	Endmill	5	0	2	20.000	1.000	0,2	2,75	14'37"	
	Drilling	Carbide drill	20	-	-	1.900	570	-	-	0'10"	
(Total) machining									54'33"		



OPEN MIND Technologies AG

Argelsrieder Feld 5 • 82234 Wessling • Germany Phone: +49-81 53-93 35 00 • Fax: +49-81 53-93 35 01 E-mail: Info.Europe@openmind-tech.com Internet: www.openmind-tech.com



AgieCharmilles

Mikron Agie Charmilles AG

HSM Competence Ipsachstrasse 16 • 2560 Nidau • Switzerland

Phone: +41-32-366 11 11 • Fax: +41-32-366 11 66 E-mail: info@mikron-ac.com Internet: www.gfac.com